



This quick reference guide to laundry accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

Step 1 Find your model number.

Step 2 Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- Gas or electric dryer?
- Side-by-side or stacked installation?
- If installing side-by-side, do you want pedestals?
- If purchasing a gas dryer, is your home natural gas (NG) or liquid propane (LP)?

Step 3 Identify the items you need to purchase for your laundry appliance.

Where to purchase accessories

Accessories can be purchased in-store with unit, or from LG Canada Parts & Accessories:

[Shop online at LGCanadaParts.com](https://www.lgcanadaparts.com)

Call 1-855-341-2732



Contents

WashTower™	2
Washers	3
Dryers	4
WashCombo™	5
Styler	6

LG WashTower™ accessory guide

		WashTower™ with electric dryer				WashTower™ with gas dryer	WashTower™ with heat pump dryer (no venting required)		
		SWWE50N3*	WKEX300HBA*	WKEX200HBA*	WKE100HWA	WKGX201HBA*	WKHC252HBA	WKHC152HWA	
Water supply requirements Washers must be connected to cold and hot water supplies (hot water supply requires a temperature range between 120°F and 130°F). Required min. / max. water pressure is 20–120 psi.		Required purchase	Washer water supply hoses (hot & cold)						
		Required purchase	Dryer water supply hoses (cold) (only required for steam dryers with * in listing above)					Not applicable	
		Included	All WashTower™ laundry machines with steam drying (listed with * above) come supplied with a Y-connector					Not applicable	
Electrical requirements LG WashTower™ laundry machines have 2 power cords attached to the unit.		Included	3-Prong power cord for washer						
		Required purchase	Washer power cord connects to a 120 V, 60 Hz, 3-prong outlet						
		Included	4-Prong power cord for dryer				3-Prong power cord for dryer	4-Prong power cord for dryer	
		Required purchase	Dryer power cord connects to a 240 V, 30 Amp circuit				Dryer power cord connects to a 120 V, 15 Amp circuit	Dryer power cord connects to a 240 V, 30 Amp circuit	
Dryer venting requirements (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)		Required purchase	All vented dryers require a dryer vent kit (All dryers are shipped for rear venting, side vent kits are available, see below)					Not required	
		Required purchase	Not applicable				Gas dryers require a flexible stainless steel gas connector kit		Not applicable
LP conversion kit If ordering a gas dryer and your home uses liquid propane (LP) instead of natural gas (NG), order an LP conversion kit.		Required purchase	Not applicable				LP conversion kit – 383EEL3002R	Not applicable	
Side vent kit All dryers are shipped for rear venting. Order a side adapter kit to change venting to the side. (Right side venting is not available on gas dryers)		Optional purchase	Side vent kit – 3911EZ9131X (Only required if you are not venting from the rear)					Not applicable	
Drying rack Order a drying rack to gently dry shoes, delicate sweaters and more, without tumbling.		Optional purchase	Drying rack included with SWWE50N3 Drying rack for 27" models (3750EL1001A) - purchase separately for WKEX300HBA, WKEX200HBA, WKE100HWA, WKGX201HBA, WKHC202HBA Drying rack for 24" model (3751EL1002M) - purchase separately for WKHC152HWA						

*Steam dryer





















Accessories can be purchased in-store with unit, or from LG Parts & Accessories:

Shop online at [LgCanadaParts.com](https://www.lgcanadaparts.com)

Call 1-855-341-2732

LG washer accessory guide

Front load washers	Top load washers	Compact front load washer
 WM8900HBA  WM6700HBA  WM6500HBA  WM5500HVA	 WT8600CB  WT8405C_(B/W)  WT8400CW	 WM1455HWA
 WM3850HVA  WM3600HWA  WM3400CW	 WT7155CW  WT7150CW  WT6105CW	

Water supply requirements Washers must be connected to cold and hot water supplies (hot water supply requires a temperature range between 120°F and 130°F). Required min. / max. water pressure is 20–120 psi.		Required purchase	Washer water supply hoses (hot & cold)		
Electrical requirements Washers have a power cord attached to the unit.		Included	3-Prong power cord for washer		
		Required purchase	Washer power cord connects to a 120 V, 60 Hz, 3-prong outlet		
Pedestal When installing side-by-side, you can add a pedestal or an LG SideKick™. (Be sure to order the correct colour to match your pair.)		Optional purchase	27" Pedestal (13 5/8" H) – WDP6_(V, B, W) (only for use with WM6700HBA, WM6500HBA, WM5500HVA, WM3850HVA, WM3600HWA, WM3400CW) 29" Pedestal – WDP5B (only for use with WM8900HBA)	Not applicable	Not applicable
		Optional purchase	27" LG SideKick™ pedestal washer – WD300C_ (V, B, W) (Includes all hoses and connectors) (only for use with WM6700HBA, WM6500HBA, WM5500HVA, WM3850HVA, WM3600HWA, WM3400CW) 29" LG SideKick™ pedestal washer – WD200CB (Includes all hoses and connectors) (only for use with WM8900HBA)	Not applicable	Not applicable





























Accessories can be purchased in-store with unit, or from LG Parts & Accessories:

Shop online at LGCANADAPARTS.COM

Call 1-855-341-2732

LG dryer accessory guide

Electric dryers	Gas dryers	Heat pump dryers
 DLEX8900B  DLEX6700B  DLEX6500B  DLEX5500V  DLEX3850V  DLE3600W	 DLGX5501V  DLG3601W	 DLHC6702B  DLHC5502V
 DLE3400W  DLEX8600BE  DLE8400_(BE/VE)  DLE7150W  DLE6100W		 DLHC1455W

Water supply requirements Dryers must be connected to a cold water supplies.		Included	Steam dryer water supply hoses (cold) (only included with DLEX7900_, DLEX7300VE, DLEX7250W)		
		Required purchase	Steam dryer water supply hoses (cold) (sold separately for DLEX8900B, DLEX6700B, DLEX6500B, DLEX5500V, DLGX5501V, DLEX3850V)		Not applicable
		Included	Y-connector already included with all steam dryers (DLEX8900B, DLEX6700B, DLEX6500B, DLEX5500V, DLEX3850V, DLEX7900_(BE/VE), DLEX7300VE, DLEX7250W)		Not applicable
Electrical requirements Dryers have a power cord attached to the unit.		Included	4-Prong power cord	3-Prong power cord	4-Prong power cord
		Required purchase	Dryer power cord connects to a 240 V, 30 Amp circuit	Dryer power cord connects to a 120 V, 15 Amp circuit	Dryer power cord connects to a 240 V, 15 Amp Circuit (DLHC1455W 30 Amp circuit)
Dryer venting requirements (Note: Venting ductwork is not provided and should be purchased separately, if required. Gas dryers must vent to the outside. For gas dryers, your laundry room must have a rigid gas supply line to your dryer.)		Required purchase	All vented dryers require a dryer vent kit (All dryers are shipped for rear venting, side vent kits are available, see below)		Not applicable
		Required purchase	Not applicable	Gas dryers require a flexible stainless steel gas connector kit	Not applicable
LP conversion kit If ordering a gas dryer and your home uses liquid propane (LP) instead of natural gas (NG), order an LP conversion kit.		Optional purchase	Not applicable	LP conversion kit – 383EEL3002R	Not applicable
Pedestal When installing side-by-side, you can add a pedestal. (Be sure to order the correct colour to match your pair.)		Optional purchase	27" Pedestal (13 5/8" H) – WDP6_(V, B, W) (only for use with DLEX6700B, DLHC6702B, DLEX6500B, DLEX5500V, DLHC5502V, DLGX5501V, DLEX3850V, DLE3600W, DLE3400W)		
			29" Pedestal – WDP5B (only for use with DLEX8900B)		
Stacking kit When installing in a stacked configuration, you must order a stacking kit.		Optional purchase	27" Stacking kit – KSTK4 (DLEX6700B, DLEX6500B, DLEX5500V, DLGX5501V, DLEX3850V, DLE3600W, DLE3400W)		
			27" Heat pump stacking kit - HSTK1B (DLHC6702B, DLHC5502V)		
Side vent kit All dryers are shipped for rear venting. Order a side adapter kit to change venting to the side. (Right side venting is not available on gas dryers.)		Optional purchase	29" Stacking kit – KSTK2 (DLEX8900B)		Not Applicable
			24" Stacking kit - 5001EL2001H included (DLHC1455W)		
Drying rack Order a drying rack to gently dry shoes, delicate sweaters and more, without tumbling.		Optional purchase	Front load drying rack - 3750EL1001A (DLEX6700B, DLHC6702B, DLEX6500B, DLEX5500V, DLHC5502V, DLGX5501V, DLEX3850V, DLE3600W, DLE3400W)		
			Top load drying rack - 3750EL0001C (DLEX7900_(BE/VE), DLEX7300VE, DLEX7250W, DLE7150W, DLE6100W)		
			Drying rack for 24" compact model - 3751EL1002M (DLHC1455W)		



LG WashCombo™ accessory guide

27" All-in-One
Washer/dryer WashCombo™

24" All-in-One
Washer/dryer WashCombo™



WM3998HBA




WM6998HBA



WM3555HVA

Water supply requirements


Washers must be connected to cold and hot water supplies (hot water supply requires a temperature range between 120°F and 130°F). Required min. / max. water pressure is 20 –120 psi.



Required
purchase

Washer water supply hoses (hot & cold)

Electrical requirements




Included

3-Prong power cord

Required
purchase

WashCombo™ power cord connects to a 120 V, 60 Hz grounded 3-prong outlet (15 Amps)

Dryer venting requirements




Not applicable

Ventless HeatPump™ drying does not require venting

Ventless condensing drying does not require venting

Pedestal


You can add a pedestal or an LG SideKick™.
(Be sure to order the correct colour to match your WashCombo™)



Optional
purchase

Pedestal – WDP6B

Not applicable



Optional
purchase

LG SideKick™ – WD300CB
(Includes all hoses and connectors)

Not applicable



Accessories can be purchased in-store with unit, or from LG Parts & Accessories:

Shop online at LGCANADAPARTS.COM

Call 1-855-341-2732











LG styler accessory guide



S5MSB



S3MFBN

Water supply requirements Stylers do not connect to a cold or hot water supply. This allows for installation in any room of the home, as there are no permanent plumbing requirements.		Included	Styler is equipped with 2 water tanks - a fill tank and a drain tank (These tanks are manually filled and emptied)	
		Included	Drip tray is included and used to catch any drips that may occur when filling or emptying the water tanks	
Electrical requirements		Included	3-Prong power cord	
		Required purchase	Connects to a 120 V, 60 Hz grounded 3-prong outlet (15 Amps)	
Dryer venting requirements		Not applicable	Ventless HeatPump™ drying does not require venting	
Leveling		Included	2 Rear leveling feet included - AFC72755402 Rear leveling feet may be used to ensure proper leveling	
		Included	4 Carpet spikes included - MFA63122901 If installed on carpet, additional carpet spikes may be used for added stability	
		Included	2 Non skid pads included Depending on the type of flooring, non skid pads may be used to prevent shaking and shifting when opening the door	
Regular hanger		Included	3 hangers included (5 hanger slots available) Regular hangers - AEE73009503	3 hangers included (3 hanger slots available)
Pants hanger		Included	1 Pants hanger included - AEE73189701	
Shelf		Included	1 Shelf included - AHT74073801	